

6v to 12v Conversion Battery Ignition

Change original generator pulley over to new alternator. Mount alternator to existing generator bracket. Best belt alignment may be with threaded alternator mounting lug on the bottom and wide mounting lug on top. Use existing fan belt. Fabricate additional strap for attaching existing top belt adjusting bracket. Wires attached to ammeter will need moved to opposite posts due to reversing of battery ground. Wire 'A' is originally attached to B terminal of cut out on generator. Wire 'B' is new wire or rerouted original wire that ran from generator F terminal to 3 position switch on dash.

* Indicates existing wire in original tractor harness

